

220 VOLT A.C. MODIFICATION KIT

Figure-1
110 VAC POWER CABLE





Figure-2
220 VAC POWER CABLE



INSTRUCTIONS FOR 200-240 VAC OPERATION

REMOVE POWER CORD DURING MODIFICATIONS

1. Remove the top cover by removing the 4 screws holding the bottom feet.
2. Locate the power cable that connects the power entry module to the power supply PC board. Figure-1 shows how this cable is wired for 110 VAC operation.
3. Rewire the Molex connector (i.e. P1) that plugs into the power supply board so that it is wired as shown in Figure-2.
4. Remove the 250 mA fuse located in the power entry module and replace it with the 125 mA fuse provided. NOTE that both of these fuses are the Time-Delay Type.
5. Attach the Fuse/Voltage Information Label provided to the rear panel, just above the power entry module. Make sure that the old fuse information is covered up.

CROMACK INDUSTRIES, INC.		
Title CEC-10A & IFR AC510 - 220 VAC FIELD MODIFICATION KIT		
Size A	Document Number DOC-OPTION-03	Rev C
Date:	Tuesday, August 31, 2004	Sheet 1 of 1